



SSD62xx Series (Marvell NevoX RAID Solution)

CLI User Guide

Table of Contents

| | |
|-----------------------------------------------------------------------|----------|
| Table of Contents..... | 2 |
| 1 MNV_CLI Software Utility User Guide | 3 |
| 1.1 Introduction..... | 3 |
| 1.2 CLI Features..... | 3 |
| 1.3 Starting the CLI Utility | 4 |
| 1.3.1 Starting Linux MNV_CLI..... | 4 |
| 1.3.2 Starting Windows MNV_CLI | 4 |
| 1.4 Command Conventions and Built-in Help | 4 |
| 1.4.1 Usage..... | 5 |
| 1.4.2 Conventions and Built-in Help..... | 5 |
| 1.4.3 How to send command to specific adapter via non-shell mode..... | 7 |
| 1.5 Support Commands and Operations..... | 7 |
| 1.5.1 adapter..... | 7 |
| 1.5.2 create | 8 |
| 1.5.3 delete | 9 |
| 1.5.4 flash..... | 10 |
| 1.5.5 smart..... | 11 |
| 1.5.6 spi..... | 12 |
| 1.5.7 set | 13 |
| 1.5.8 get..... | 13 |
| 1.5.9 vd..... | 14 |
| 1.5.10 log..... | 15 |
| 1.5.11 reset..... | 16 |
| 1.5.12 vpd..... | 17 |
| 1.5.13 ns..... | 18 |
| 1.5.14 dumphba..... | 20 |
| 1.5.15 event..... | 22 |
| 1.5.16 import..... | 23 |
| 1.5.17 info | 23 |
| 1.5.18 init | 24 |
| 1.5.19 rebuild | 25 |
| 1.5.20 mp..... | 26 |
| 1.5.21 passthru | 27 |
| 1.5.22 vpdread..... | 28 |
| 1.5.23 vpdwrite | 29 |

1

MNV_CLI Software Utility User Guide

This document contains the following sections:

- Introduction
- CLI Features
- Starting the CLI Utility
- Command Conventions and Built-in Help

How to send command to specific adapter via non-shell mode

Non-shell mode

Command

```
mnv_cli [<NVMe Controller ID>] <COMMAND> <OPTIONS>
```

Default NVMe Controller ID is 0.

| Example | Description |
|----------------------|-------------------------------------------------|
| mnv_cli 1 info -o pd | Show all PD information of NVMe Controller ID 1 |

- Support Commands and Operations

1.1

Introduction

Marvell 88NR2241 mnv_cli utility Command Line Utility provides a user interface to manage the 88NR2241 (88NR2241) NVMe controller. This document lists the formats and commands of the CLI utility.

1.2

CLI Features

- Switch adapter (controller)
- View adapter, virtual disk and physical disk information
- Create a virtual disk (RAID only)
- Delete a virtual disk (RAID only)
- Namespace attachment
- View SMART of physical disk
- Set, get configuration of adapter and virtual disk (RAID only)
- Flash adapter or physical firmware image

- Rebuild and initialize a virtual disk (RAID only)
- Run media patrol on a virtual disk (RAID only)
- Read event
- Import virtual disk
- Import PD (JBOF only)
- Dump UART information
- Simple API command {VD create/delete, GPIO, Dump SPI, VPD target switch, dump HBA info and GPIO setting for HBA info.}
- Show CLI/API version
- Passthrough NVMe admin command to back-end device
- MI VPD read/write (Linux only)
- OEM data read/write

1.3 Starting the CLI Utility

1.3.1 Starting Linux MNV_CLI

User shall add executable permission for `mnv_cli` > `chmod 777 mnv_cli`

To enter into CLI prompt: `shell > sudo ./mnv_cli`

1.3.2 Starting Windows MNV_CLI

Run // double click `mnv_cli.exe` program. A Windows CMD Windows starts.

Limitations:

- In Windows, if the 88NR2241 adapter does not have a functional VD presented to the OS, the CLI and API cannot find the adapter. This is a Windows inbox driver limitation.
- Windows driver does not support NVMe notification and hot-plug. Hence, any newly created VD by CLI utility is not detected by Windows until the OS is rebooted (alternatively, the user can try disable/enable 88NR2241 NVMe controller and driver to force a device re-scan).
- Ns (Name Space) admin is not supported by Windows drivers.
- If current user not administrator, please run `mnv_cli.exe` with administrator permission.

1.4 Command Conventions and Built-in Help

This command line utility now can be used in both Linux and Windows environment. When the utility is used in the OS shell, the syntax is:

`mnv_cli [adapter id] command [<parameter ...>] [-output <file>]`

`-output` redirects output to the file.

When the utility is used in shell mode, the syntax is:

`command [<parameter ...>]`

| | |
|------------------------------------|------------------------------------------------------------------------------------------------------------|
| get | Get configuration information of NVMe Controller or VD. |
| set | Set configuration parameters of VD or NVMe Controller. |
| smart | Get SSD adapter smart info. |
| flash | Update flash image. |
| adapter | Default NVMe Controller the following CLI commands refers to. |
| version | Show API and CLI version |
| passthru | Passthrough NVMe admin command to back-end device |
| spi | Read and write SPI data. Maximal size of SPI data is 512 bytes. |
| vd | Simple API for VD create and delete |
| log | Simple API for show/on/off SPI log |
| reset | Simple API for reset back-end device |
| Note: | |
| <Default GPIO setting> | |
| Set power: | |
| Power pin id 0 means control GPIO4 | |
| Power pin id 1 means control GPIO5 | |
| Set perstn | |
| PD id 0 means control GPIO8 | |
| PD id 1 means control GPIO9 | |
| PD id 2 means control GPIO10 | |
| PD id 3 means control GPIO11 | |
| led | Simple API for control LED of device |
| vpd | Simple API for switch VPD access target |
| info | Simple API for display adapter (HBA), virtual disk (VD), physical disk (PD) or Namespace (NS) information. |
| event | Simple API for getting event from NVMe Controller. |
| import | Simple API for import VD |
| init | Simple API for start or stop VD initialization. |
| mp | Simple API for start or stop media patrol for a virtual disk. |
| rebuild | Simple API for start or stop VD rebuild. |
| ns | Simple API for namespace management |
| dumphba | Simple API for dump HBA info data structure |
| gpio | Simple API for GPIO setting in HBA info (Only for GPIO 4 to 7) |
| debuglv | Simple API for switch debug level target |
| oemdata | Simple API for write OEM data. |
| vpdread | Read VPD via standard MI-Send and MI-Receive |
| vpdwrite | Write VPD via standard MI-Send |

1.5.10 log

Objective

This command is a Simple API feature to create debug log via Simple API. The function works as a dump.

Command

```
log <-a show [--outputfile=log.txt] | on | off > [-h]
```

Parameters

| | | |
|----|------------------------------|------------------------------------------------------------------|
| -a | --action show and set on/off | show: show SPI log on: enable SPI log off: disable SPI log |
| | --outputfile <outputfile> | Output the data into the output file. |
| -h | --help | |

Example

| | |
|----------------------------------|-----------------------------------------------|
| log -a show | Show SPI log. |
| log -a show --outputfile=log.txt | Show SPI log into the text file named log.txt |
| log -a on | Enable SPI log. |
| log -a off | Disable SPI log. |

1.5.11 reset

Objective

This command is a Simple API feature to reset the back-end device. Once the Simple API SDK is complete, this feature is removed from the CLI tool.

Command

```
reset -i <pdid> -t <device | perstn | power -a <cycle|on|off> > [-h]
```

Note:

| |
|---------------------------------------------------------------------------------------------------------------------------------------|
| <Default GPIO setting> |
| Set power: pdid 0 means control GPIO4 pdid 1 means control GPIO5 |
| Set perstn: pdid 0 means control GPIO8 pdid 1 means control GPIO9 pdid 2 means control GPIO10 pdid 3 means control GPIO11 |

Parameters

| | | |
|----|----------|----------------------------------------------------------------------------------------------------------------------|
| -i | --pdid | |
| -t | --type | device: devbitmap and power device, device disable and enable power: power off and on perstn: PCIe reset cycle |
| -a | --action | power: cycle on and off only cycle: for power off and on a cycle (Default) on: power on off: power off |
| -h | --help | |

Example

| | |
|------------------------------|----------------------------------------|
| reset -i 0 -t device | Device PD ID 0 as reset cycle. |
| reset -i 1 -t perstn | Device PD ID 1 as PCIe cycle reset. |
| reset -i 1 -t power -a cycle | Device PD ID 1 as a power cycle reset. |
| reset -i 1 -t power -a on | Device PD ID 1 as power on. |
| reset -i 1 -t power -a off | Device PD ID 1 as power off. |

1.5.12 vpd

Objective

This command is a Simple API feature to switch VPD access target via Simple API.

Command

```
vpd <-t eeprom|spi > [-h]
```

| | | |
|----|----------|---------------------------------------------------------------------------------------------------|
| -t | --target | Set access EEPROM or SPI. eeprom, set access target to EEPROM spi, set access target to SPI |
| -h | --help | |

Example

| | |
|---------------|------------------------------|
| vpd -t eeprom | Set access target to EEPROM. |
| vpd -t spi | Set access target to SPI. |

1.5.13 ns

Objective

This is a Simple API feature to switch VPD access target via Simple API. It is used for namespace management.

Command

```
ns -p | -a <init -i <pdid> -n <number of namespace> | share -s  
[yes|no] [-i <ns id> | -e <eui64>] | create -i <pdid|vdid> -c  
<ctrlid> -l<LBA size> | [attach|detach] [-i <ns id> | -e <eui64>] -d  
<ctrl id list> > [-h]
```

Parameters

| | | |
|----|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| -p | --primary <ctrl id> | Show primary controller ID. |
| -a | --actions init, share, create, attach and detach | init: initial namespace for specific instance (JBOF only) share: setting NMIC of namespace for private or sharing (JBOF only) create: create namespace (JBOF only) attach: attach namespace detach: detach namespace |
| -i | --id <pd id ns id vd id> | For init action, need input one PD ID. For share action, need input one namespace ID. For create action, need input one PD/VD id. |
| -e | --EUI64 <ns unique identifier | Notice: only support attached namespace For share action, need input one EUI64 identifier id or namespace id |

1.5.14 dumphba

Objective

This is a Simple API feature to switch VPD access target via Simple API. It is used to dump hba info data structure.

Command

```
dumphba [--outputfile <outputfile>] [-a show] [-h]
```

Parameters

| | | |
|----|---------------------------|----------------------------------------|
| | --outputfile <outputfile> | Output data into the output file. |
| -a | --show | Show parts value of HBA info readable. |
| -h | --help | |

Example

| | |
|-------------------------------|-------------------------------------|
| Dumphba | Output raw data |
| dumphba --outputfile=raw_data | Output raw data into file raw_data. |
| dumphba -a show | Output parts value of HBA info. |

1.5.15 event

Objective

To get the newest event from the adapter.

Command

```
event [-c event count] [-h]
```

Parameters

| | | |
|----|-----------------------|---------------------------------------------------------------------------------------------------------|
| -c | --count <event count> | If count is zero, it will show all events If count is not zero, it will show latest specific events. |
| -h | --help | |

Return

| | |
|----|---------|
| 0: | success |
|----|---------|

Example

| | |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Event -c 0 | Get events from current NVMe Controller. For the current design, it displays all the event pages. It is 4k/per page and the total number of pages is 16. |
| event -c 20 | Get latest 20 events from current NVMe Controller. |

1.5.16 import

Objective

This command is a Simple API feature to import a VD when an importable VD roams from one controller to another. If NVMe Controller supports the RAID mode, this function will import VD.

If VD is created from one controller and the SSD with VD roamed to another controller, the VD needs to be imported first before the firmware reports the VD to the OS.

Note: The user can use > info -o VD command to check if the VD status to be imported or not.

Command

```
import [-i <NVMe Controller ID>] -l <VD ID>
```

Parameters

| | | |
|----|---------------------------|--------------------------------------------------------------------------------------------------|
| -i | --id <NVMe Controller ID> | Select ID of the NVMe Controller. If -i is not specified, display current NVMe Controller ID. |
| -l | --ldid <VD ID> | ID of the VD to be selected. |
| -h | --help | |

Example

| | |
|------------------|----------------------------------------|
| import -i 0 -l 0 | Import VD ID 0 into NVMe Controller 0. |
|------------------|----------------------------------------|

1.5.17 info

Objective

This command is a Simple API feature to display NVMe controllers/physical disks/virtual disks info. It dumps the information of NVMe controller, virtual disks or physical disks.

Command

```
info -o <hba|vd|pd|ns [-t <host|vd> [-v <vd_id>]] > [-i <id>] [-h]
```


1.5.20 mp

Objective

This command is a Simple API feature to start or stop media patrol for a virtual disk.

Command

```
mp [-a <start|stop>] -i <VDID> [-h]
```

Note: This feature only works with VD whose RAID is RAID1 or RAID10 and functional. When the status is paused, it cannot abort until the status is running. Does not support JBOF mode.

Parameters

| | | |
|----|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| -a | --action <start stop> | (DEFAULT:start) - media patrol action to be performed on a VD. Only RAID1 and RAID10 support media patrol. If VD is not functional, media patrol may fail. |
| -i | --vdid <VDID> | VD ID. |
| -h | --help | |

Return

| | |
|----|---------|
| 0: | success |
| 1: | failure |

Example

| | |
|------------------|-----------------------------|
| mp -a start -i 0 | Start media patrol on VD 0. |
| mp -a stop -i 0 | Stop media patrol on VD 0. |

1.5.21 passthru

Objective

This command is a pass-through NVMe admin command to the back-end device.

Command

```
passthru -t <admin> -r <read | write> -i <SSD adapter id>  
[-o <opcode>]  
[-n <ns id>] [--cdw2=<cdw2>] [--cdw3=<cdw3>]  
[--cdw10=<cdw10>] [--cdw11=<cdw11>] [--cdw12=<cdw12>]  
[--cdw13=<cdw13>]  
[-d <data-len>]  
[--outputfile <outfile>] [--inputfile <infile>]  
[--showcmd] [-h]
```

Note: CDW14 and CDW15 are used by passthru command.



Thank you